

Auxiliary Memory Configurations

Figure 1 shows the 1 Megabyte memory space partitioned into 128K segments. Switch settings (SW) and jumper connections (E) are shown for all possible memory configurations. Figure 2 shows physical locations of switches and jumpers on the 128K and 384K auxiliary memory boards.




Figure 1: Memory Space Segments




Figure 2: Memory Configuration Switches and Jumpers

Part Number 101460

DS-1



380 El Pueblo Road
Scotts Valley, CA 95066 USA
408/438-6650

As I do not have access to photo copier I have typed out the information that I have on memory symbols.

Memory in machine including that on motherboard	Number displayed at Boot up
---	--------------------------------

128k	M2000
192k	M3000
256k	MA000
320k	M5000
384k	M6000
448k	M7000
512k	M8000
576k	M9000
640k	MA000
704k	MB000
768k	MC000
832k	MD000
896k	ME000

The dil switch settings
for the 128k Simon
board.



Information from Intelligence Research Ltd.